ISOVOX

ISOPOP BROADCAST

INSTALLATION AND USER INSTRUCTIONS | Version 1.00 | 2024

INTENDED USE

The ISOPOP™ BROADCAST is intended to be used as a mountable pop filter for professional vocal recording. The ISOPOP™ BROADCAST is intended to be used on front address microphones. The ISOPOP™ BROADCAST should only be used in households, normal recording studios or similar environments.

The product shall only be used according to the instructions as described in this manual. All use other than described in this manual is seen as unintended use. This will also invalidate the warranty.

⚠WARNING

SAFETY INSTRUCTIONS


Read and understand this manual and its safety instructions before using this product. Failure to do so can result in injury or material damage.

- Never leave children unattended with the packaging material. The packaging material represents a danger of suffocation. Children frequently underestimate the dangers. Always keep children away from the packaging material. The ISOPOP™ BROADCAST is not a toy.
- Never leave children unattended with the product. The product is made out of small components that may form a choking hazard.
- Do not try to force objects larger than Ø6 cm/2,36" in diameter into the housing - this might scratch both the object and the ISOPOP™ BROADCAST.
- Do not play with the rubber bands, they can snap off and cause injury.
- Do not twist the rubber bands around fingers or any other body parts, there is a risk of hindering blood flow.
- Only use the product when correctly and completely installed. Be aware that the manufacturer cannot be held responsible for personal injuries, equipment- and/or material damage resulting from the incorrect installation of the product.

Always keep the instructions for future reference. The information in this manual is subject to change without notice.

PRODUCT ELEMENTS


Ⓐ Housing
Ⓑ Rubber Bands
Ⓒ Position Grooves
Ⓓ Pop Filter




HOW TO INSTALL THE ISOPOP™ BROADCAST

Video instructions available at isovoxbooth.com/pages/setup-bc

1. Take three rubber bands Ⓑ and set aside the rest.
2. Mount two rubber bands near the bottom position groove Ⓒ on the Housing Ⓐ.
3. Mount one rubber band at the opening of the Housing.
4. Put your microphone of choice in between the first rubber band and gently slide the housing on to the microphone.





5. Take the next rubber band and gently pull it around the microphone and roll it into one of the position grooves.
6. Repeat step 6 with the last Rubber Band and adjust the position of the Housing.
7. Insert pop filter Ⓓ of choice into the housing.



HOW TO CLEAN THE ISOPOP™ BROADCAST

1. Push the pop filter Ⓓ out of the housing Ⓐ.
2. Clean the pop filter with water under a faucet.
3. Gently squeeze the excess water out of the popfilter and leave to dry.
4. Push the pop filter back into the housing.





NOTICE

Make sure the pop filter is dry before pushing it back into the housing. Water may drip onto the microphone and cause damage if the filter is wet.

DISPOSAL

The packaging is made of environmentally friendly materials, which may be disposed of through your local recycling facilities. By disposing of the packaging and packaging waste in the proper manner, you help to avoid possible hazards for the environment and public health.

ISOVOX AB, Skyttevägen 41, 302 44, Halmstad, Sweden - isovoxbooth.com